

IDO-EVB3568-V1 Linux5.10开发手册

1、源码获取

[1.1 下载源码](#)

[1.2 解压源码](#)

2、开发环境搭建

3、SDK编译

[3.1 选择屏幕配置](#)

[3.2 文件系统选择](#)

[3.3 开始编译](#)

[3.3.1 一键编译](#)

[3.3.2 部分编译](#)

4、FAQ



IDO-EVB3568-V1

Linux5.10开发手册

深圳触觉智能科技有限公司

www.industio.cn

文档修订历史

版本	PCBA版本	修订内容	修订	审核	日期
V1.0	V1D	创建文档	TWX	IDO	2024/11/27

1、源码获取

1.1 下载源码

链接: <https://pan.baidu.com/s/1Jg9DYMssLLFYjLpD8zo4Gw?pwd=1234>

提取码: 1234

1.2 解压源码

```
1 $ cat ido-evb3568-v1d-Linux5.10-sdk-V1.1-241220.tar.gz.a* > ido-evb3568-v1d-Linux5.10-sdk-V1.1-241220.tar.gz
2 $ tar -zxvf ido-evb3568-v1d-Linux5.10-sdk-V1.1-241220.tar.gz
```

解压得到ido-evb3568-v1d-Linux5.10-sdk目录即为SDK目录。

2、开发环境搭建

建议使用Ubuntu18.04及以上版本系统上开发，并安装依赖软件包。

```
1 sudo apt-get install repo git ssh make gcc libssl-dev liblz4-tool expect
2 sudo apt-get install g++ patchelf chrpath gawk texinfo chrpath diffstat
3 sudo apt-get install binfmt-support qemu-user-static live-build bison flex
4 sudo apt-get install fakeroot cmake gcc-multilib g++-multilib unzip
5 sudo apt-get install device-tree-compiler python-pip libncurses5-dev python
-pyelftools
```

3、SDK编译

3.1 选择屏幕配置

```


1 $ ./build.sh lunch
2 1. rockchip_rk3568_EVB3568V1_HDMI_EDP-1920x1080_defconfig
3 2. rockchip_rk3568_EVB3568V1_HDMI_LVDS-1024x600_defconfig
4 3. rockchip_rk3568_EVB3568V1_HDMI_MIPI1-1200x1920_Buildroot_defconfig
5 4. rockchip_rk3568_EVB3568V1_HDMI_MIPI1-1200x1920_Debian_defconfig
6 5. rockchip_rk3568_EVB3568V1_HDMI_MIPI1-1200x1920_Ubuntu_defconfig
7 6. rockchip_rk3568_EVB3568V1_HDMI_MIPI2LVDS-1920x1080_defconfig
8 7. rockchip_rk3568_EVB3568V1_HDMI_defconfig

```

每个defconfig配置对应的显示屏不同。

3.2 文件系统选择

通过环境变量RK_ROOTFS_SYSTEM进行文件系统的选择：



例如选择debian文件系统，则将RK_ROOTFS_SYSTEM赋值debian：

```
1 export RK_ROOTFS_SYSTEM=debian
```

3.3 开始编译

3.3.1 一键编译

```
1 $ ./build.sh
```

如果前面lunch切换过mk，则编译会弹出IO Domain Checklist弹窗：

| IO Domain Checklist |
Get the corresponding value from the hardware schematic diagram

```
18000000 PMUI02 Supply Power Voltage(uV)  
33000000 PMUI02 Supply Power Voltage(uV)
```

<0k>

注意vccio4 和 vccio6 选择1.8V, 其余为3.3v, 在提示弹窗内, 使用键盘上下键选择正确的值
等待编译完成后, 将生成镜像在rockdev目录下:

```
1 $ ls rockdev/  
2 boot.img MiniLoaderAll.bin misc.img oem.img parameter.txt recovery.i  
m g rootfs.ext4 rootfs.img uboot.img update.img userdata.img
```

其中update.img为完整固件包。

3.3.2 部分编译

SDK支持单独编译某个模块, 如loader、uboot和kernel等。

以单独编译kernel为例:

```
1 $ ./build.sh kernel
```

编译完成后, 会生成rockdev/boot.img。

4、FAQ

编译Buildroot提示: g++:internal compiler error: Killed (program cclplus)

```

8/host/include -I/home/luffy/share/3568/rk356x_linux_sdk_211116/buildroot/output/rockchip_rk3568/host/include -I../../gcc../../../libdecoumber -I../../gcc../../../libdecoumber/dpd -I../../libdecoumber -I../../gcc/..
h.o -MT generic-match.o -UUUID -Wl,--no-undefined -Ldeps/generic-match -TDe_GENERIC-MATCH_C
2022-01-05T10:38:16 g++: internal compiler error: Killed (program cclplus)
2022-01-05T10:38:16 Please submit full bug report,
2022-01-05T10:38:16 with preprocessed source if appropriate.
2022-01-05T10:38:16 You can find information about how to do this in the README.Bugs file.
2022-01-05T10:38:16 Makefile:116: recipe for target 'gimple-match.o' failed
2022-01-05T10:38:16 make[3]: *** [gimple-match.o] Error 4
2022-01-05T10:38:16 make[3]: *** Waiting for unfinished jobs...
2022-01-05T10:38:23 Makefile:4300: recipe for target 'all-gcc' failed
2022-01-05T10:38:23 make[2]: *** [all-gcc] Error 2
2022-01-05T10:38:23 package/pkg-generic.mk:228: recipe for target 'host-gcc-initial-9.3.0/.stamp_built' failed
2022-01-05T10:38:23 make[1]: *** [/home/luffy/share/3568/rk356x_linux_sdk_211116/buildroot/output/rockchip_rk3568/build/host-gcc-initial-9.3.0/.stamp_built] Error 2
2022-01-05T10:38:26 /home/luffy/share/3568/rk356x_linux_sdk_211116/buildroot/output/rockchip_rk3568/Makefile:10: recipe for target '_all' failed
2022-01-05T10:38:26 make: *** [_all] Error 2
Command exited with non-zero status 1
you take 26:56:07 to build builtroot
ERROR: Running buildroot failed!
ERROR: exit code 1 from line 556
/usr/bin/time -f "you take %e to build builtroot" $COMMON_DIR/mk-buildroot.sh $BOARD_CONFIG
root@luffy-virtual-machine:/share/3568/rk356x_linux_sdk_211116# dd if=/dev/

```

提示memory 不够, 可以通过增加swap空间来避免

- 查看Swap空间大小

```

▼ Shell | ↗

1 free -m
2
3          total        used        free      shared  buff/cache   avail
4   Mem:    7868       1144       5495        352       1228
5     6095
5   Swap:   8075         0       8075

```

- 在原有的Swap基础上增加8G空间 (大小可自己定)

```

▼ Shell | ↗

1 sudo dd if=/dev/zero of=swapfile bs=1G count=8
2
3 记录了8+0 的读入
4 记录了8+0 的写出
5 8589934592 bytes (8.6 GB, 8.0 GiB) copied, 45.0893 s, 191 MB/s

```

- 创建一个Swap文件

```

▼ Shell | ↗

1 sudo mkswap /swap/swapfile
2
3 Setting up swapspace version 1, size = 8 GiB (8589930496 bytes)
4 无标签,  UUID=179cba9a-944b-458a-9e1c-c924ad578662

```

- 尝试激活Swap文件

Shell |

```
1 swapon /swap/swapfile
2
3 swapon: /swap/swapfile: 不安全的权限 0644, 建议使用 0600。
4 swapon: /swap/swapfile: swapon 失败: 不允许的操作
```

- 修改文件权限

Shell |

```
1 chmod 0600 /swap/swapfile
```

- 再次查看Swap空间大小

Shell |

```
1 free -m
2
3   total     used     free   shared  buff/cache  avail
4   Mem:      7868     1178     1174      371      5516
5   Swap:    16267       0     16267
6
```

- 重启计算机可能会退回8G，如果需要一直保持这个swap空间，可以把它写入/etc/fstab文件中

Shell |

```
1 sudo vim /etc/fstab
2
3 #增加以下两行:
4
5 (add swap space on /swap/swapfile)
6 /swap/swapfile          /swap      swap    defaults
7
```